



AN 182

Cleanroom Materials as Sources of Airborne Molecular Contamination

May 4, 2007 (Version 3.0)

Discussion

Every material introduced into a cleanroom is a potential source of Airborne Molecular Contamination (AMC). The chemical composition of a material, its surface area and its temperature ultimately determine the levels of contamination introduced into the cleanroom environment. Those contaminants that condense on critical process components can lead to “AMC defects” such as changes in the electrical properties of wafers, uncontrolled boron and phosphorus doping, etch rate shifts, threshold voltage shifts, wafer and stepper optics hazing and high contact resistance. As line widths of microelectronic devices shrink “AMC defects” have become a major concern and will need to be considered in the design of future cleanrooms.

The condensable Airborne Molecular Contamination arising from various cleanroom materials has been studied by means of FTIR, GC/MS and TOF-SIMS. In addition, the transfer of contaminants by direct contact was analyzed. The latter is of interest since contact transfer may result in the spread of contaminants over a large area of the cleanroom. In both experiments silicon wafers were used as substrate material. Table 1 summarizes the results for different parts of a cleanroom chair and from 3 different cleanroom gloves. The letter indicates the technique by which a contaminant was detected, the color of the letter indicates whether a contaminant was detected as condensable AMC (black) or by contact transfer on a wafer (red). Due to its high sensitivity for most condensable AMCs, TOF-SIMS detects a significantly larger number of contaminants than GC/MS or FTIR. TOF-SIMS also allows for detection of contaminants transferred by contact. The ability to identify specific contaminants with high sensitivity is of critical importance to meet requirements for future contamination control and for an optimized selection of cleanroom materials.

Contaminants	Cleanroom Chair				Cleanroom Gloves		
	Seat Bottom	Foam Seat	Seat Cover	Wheel	Glove A	Glove B	Glove C
Plasticizer: phthalates, adipate	TF	F				T	
Antioxidants: BHT etc.						T	G
Fatty Acid Amides			TT			T	T
Alcohol Amines, other C _x H _y NO	T		T	T	TT	F	
Fatty Acides					T		TT
Other Organic Acids							F
Amines		TTFG	TT		FT	TFT	T
Esters							F
Sulfates, Sulfonates, etc.						T	T
Triphenyl-phosphate	TTF	G	TTFG				
Silicones	T			T	T	T	TTF
Aromatic C _x H _y O _z							T
High Molecular C _x H _y							F
Fluorocarbons					T		

United States Locations

Tempe, Arizona
+1 480 239 0602 info.az@eaglabs.com
+1 602 470 2655 fax

Sunnyvale, California
810 Kifer Road
+1 408 530 3500 info.ca@eaglabs.com
+1 408 530 3501 fax

1135 E Arques Avenue
+1 408 738 3033
+1 408 738 3035 fax

785 Lucerne Drive
+1 408 737 3892
+1 408 737 3916 fax

Peabody, Massachusetts
+1 978 278 9500 info.ma@eaglabs.com
+1 978 278 9501 fax

Chanhassen, Minnesota
+1 952 828 6411 info.mn@eaglabs.com
+1 952 828 6449 fax

East Windsor, New Jersey
+1 609 371 4800 info.nj@eaglabs.com
+1 609 371 5666 fax

Syracuse, New York
+1 315 431 9900 info.ny@eaglabs.com
+1 315 431 9800 fax

Raleigh, North Carolina
+1 919 829 7041 info.nc@eaglabs.com
+1 919 829 5518 fax

Round Rock, Texas
+1 512 671 9500 info.tx@eaglabs.com
+1 512 671 9501 fax

International Locations

Shanghai, China
+ 86 21 6879 6088 info.cn@eaglabs.com
+ 86 21 6879 9086 fax

Tournefeuille, France
+ 33 5 61 73 15 29 info.fr@eaglabs.com
+ 33 5 61 73 15 67 fax

Frankfurt, Germany
+ 49 (0) 693053213 info.de@eaglabs.com
+ 49 (0) 69307941 fax

Tokyo, Japan
+ 81 3 5396 0531 info.jp@eaglabs.com
+ 81 3 5396 1930 fax

HsinChu, Taiwan
+ 886 3 5632303 info.tw@eaglabs.com
+ 886 3 5632306 fax

Uxbridge, United Kingdom
+ 44 (0) 1895 811194 info.uk@eaglabs.com
+ 44 (0) 1895 810350 fax